# CATCH Guide for SageHLS System

March, 2018

### **Overview of HLS-CATCH Process**

- 1) Prior to day of extraction, schedule availability of cells. Check that cell preparation reagents are ready.
- 2) Prepare cells using Sage HLS cell prep kit instructions (kits/protocols for mammalian WBCs, tissue culture cells, and bacterial spheroplasts are available). Recommended cell load will contain ~2.5 ug genomic DNA per lane (for example, ~375,000 human diploid cells per lane) in a maximum loading volume of 70 ul. Higher cell loads will result in lower recovery of genomic CATCH targets.
- 3) Prepare HLS cassettes for run. (Dislodge bubbles, open cassettes, empty and refill elution modules, fill electrode reservoirs with electrophoresis buffer to top edge of cassette. Perform current test.)
- 4) Assemble wild-type SpCas9 enzyme with gRNAs. (Assembly can be done in advance.)
- 5) Set up desired workflow in software.
- 6) Load samples and carry out run, including user interventions for Treatment Stage using customized Cas9 cleavases.
- 7) After run, remove tape seals and remove samples from elution modules, preferably using wide-bore pipette tips.

### HLS Software for CATCH

### **General description of HLS software**

Users will use (and create) "Workflows" comprising up to three "Stages".

The "Stages" fall into the following categories:

### Stage 1 - Extraction

Cells are lysed by a brief period of DC electrophoresis (1 or 3 hrs). Released HMW genomic DNA enters the agarose wall of the sample well, and becomes immobilized there because of its large size (>10mb).

#### <u>Stage 2 – Treatment</u>

The user adds customized Cas9 cleavases to the sample well to release genomic region(s) of interest from immobilized genomic DNA in wall of sample well.

### Stage 3 – Collection

Electrophoretic size selection is carried out to remove enzymatic reagents, separate the targeted genomic fragments from non-specific digestion products, and electroelute the products into the elution modules.

#### Main screen on instrument startup Workflow filename & selection menu Tabs address different functions of software Main Screen Workflow Editor Log Review System Option Cassette lane selectors Workflow File Nest Configuration 01 03 04 I-1 0.0 Voltage, V Lid Status Lock Status Electrophoresis Current and Sample Well Temperature System Status 80-80 0 I-2 0.0 $\sim$ 0.0 5 idle 75--75 T-1,2 0.0 🔨 70 --70 Step Table 0.0 I-3 65--65 I-4 0.0 Step Description 60--60 T-3,4 0.0 55--55 50 -₫ 45--50 40--45 5 35--40 30 --35 25--30 20 --25 15--20 10 --15 5-Time to Next User Event -10 00:00 00:05 00:10 00:15 00:20 00:25 00:30 00:35 00:40 00:45 00:50 00:55 01:00 00:00:00 Time, hh:mn Simulation mode Check drive protection 0 × Check Current Run Workflow Pause Workflow Stop Workflow Clear R Display Info Shutdown Real time current and sample well

Window showing individual workflow steps.

temperature status.

<u>Workflows</u> can be loaded from the "Main Screen" by clicking on the Workflow file directory icon, which will open a Workflow directory window. The Workflows are grouped into two categories, "Core" and "Non-core", based on how much experience Sage has had with the workflow. Double-click on the folder to see the workflow files. Workflow files have a ".shflow" filetype.

in Screen	Workflow Editor	Log Review	System Options	Stage Editor	Factory Settings	Data Acquisition
	Workflow Editor         01         02         02         02         Voltage, V         Lid Status         Lock Status         0.0         Step Table         Step         Description	Log Review	System Options Workflow File Nest Configuration 03 • Local Disk (C:) + Users + Public + Public D Name * Core_Workflows Non-Core_Workflows Rinse.shflow temp-test.shflow	Stage Editor	Factory Settings         Image: Setting sett	Data Acquisition
		🗣 Network File na	ame:		Workflow File (*.shflow)	05 Mar 2018 01:32:06 Time to Next User Event
<u>~</u>	Check Current Run Workfl				OK Car	icel Shutdown

Workflows designed for HLS-CATCH experiments include <u>"CATCH"</u> as the first term. Workflows designed for HMW DNA extraction include <u>"HMW"</u> as the first term. Some of the workflows share size-selection electrophoresis conditions, but differ in the duration of the extraction and/or collection stages. For instance the workflow "CATCH 100-300kb **extr1h sep3h**" uses a 1 hour extraction stage, and a 3 hour size-separation collection stage. The "CATCH 100-300kb **extr3h sep4h** uses the same collection waveform ("100-300kb"), but uses a 3hr extraction stage, and a 4 hour collection stage.

Screen	Workflow Editor	Log Review	System Options	Stage Editor	Factory S	ettings	Data Acquisition
			Workflow File				
			Neck Car Formation				
			Nest Comiguration				]
						<b>X</b>	
	02		(Cr) = Upara = Bublic = Bublic Documenta = Saga	Science - Saco HIS - Wa	rkflown - Coro Workflow		
			(c.) • Osers • Fubilic • Fubilic Documents • Sage	Science + Sage nics + Wo	IKINOWS + COLE_WOLKNOW	··s • 🖬	
		Organize 🔻 New folder		,	_		
Voltage	e, V Lid Status Lock Status	s 🔆 Favorites	Name ^	Date modified	Туре	Size	🗌 I-1 0.0 📉
0.0		Desktop	CATCH 100-300kb extr1h sep3h.shflow	3/5/2018 1:03 AM	SHFLOW File	1 KB	□ I-2 0.0
	Sten Table	Downloads	CATCH 100-300kb extr1h sep4h.shflow	3/5/2018 1:03 AM	SHFLOW File	1 KB	□ 1-1,2 0.0 <u></u>
		Recent Places	CATCH 100-300kb extr3h sep3h.shflow	3/5/2018 1:03 AM	SHFLOW File	1 KB	
Step	Description	📜 Libraries	CATCH 100-300kb extr3h sep4h.shflow	3/5/2018 1:03 AM	SHFLOW File	1 KB	T-34 00
		Documents	CATCH DC55V extr1h sep45m.shflow	3/5/2018 1:04 AM	SHFLOW File	1 KB	
		J Music	CATCH DC55V extr1h sep75m.shflow	3/5/2018 1:04 AM	SHFLOW File	1 KB	
		Pictures	CATCH DC55V extr3h sep45m.shflow	3/5/2018 1:05 AM	SHFLOW File	1 KB	
		Videos	CATCH DC55V extr3h sep75m.shflow	3/5/2018 1:05 AM	SHFLOW File	1 KB	
			HMW DNA extraction.shflow	3/5/2018 1:06 AM	SHFLOW File	1 KB	
		Local Disk (C:)	HMW High-Pass 50kb elu45m.shflow	3/5/2018 1:07 AM	SHFLOW File	1 KB	
		Removable Disk (D:)	HMW High-Pass 50kb.shflow	3/5/2018 1:07 AM	SHFLOW File	1 KB	Date and Time
			HMW High-Pass 300kb.shflow	3/5/2018 1:08 AM	SHFLOW File	1 KB	05 Mar 2018 01:33:15
		🙀 Network				I	
		-				I	Time to Next User Event
							00:00:00
		File n	ame:		Vorkflow File	(*.shflow)	
		The fi					
Ch Ch	neck Current 📃 🧼 Run Work	fl			OK	Cancel	Shutdown

<u>Non-core workflows</u> have been designed for special purposes. For instance, the **CATCH 100-400k** workflows are designed to have a broader collection range than the core 100-300kb workflows, whereas the "**CATCH <xxx>kb**" workflows are designed to have expanded resolution in a <u>narrow window</u> centered on <xxx>kb. In general, Sage has tested the non-core workflows with model samples, but doesn't yet have extensive test data from biological samples.



### View of the main screen after selecting a CATCH workflow.

To view the stage structure of a particular HLS workflow, it is more convenient to load the workflow into the **Workflow Editor**, as shown on the next page.

Settings Data Acquisition	Factory Settings	Stage Editor	System Options	Log Review	Workflow Editor	ain Screen
			Worktiow File			
		i sep3h	Core_Workflows\CATCH 100-300kb			
			Nest Configuration			
$ \begin{array}{c}                                     $	vle Well Temperature	ectrophoresis Current and Sampl	80 - 75 - 70 - 65 - 60 - 55 - 50 -	status System Status idle idle n ts of reagent well and sample wave index 1-1 ral. Start Cas9 Reaction: Repla	Voltage, V Lid Status Lock Status 0.0 Step Table Step Description 1-001 pause for user action 'Remove contents of re 1-002 separate for 01:00:00 at 55.0 V with wave in 2-001 pause for user action 'Remove tape seal. Sta	
-50 円 -45 앞			₩ 45 - tů 40 -	wave index 2-1 well contents with 80ul of enz	2-002 separate for 00:01:00 at 55.0 V with wave in 2-003 pause for user action 'Replace sample well co	
-40 <sup>JIP</sup>			ğ 35 -	Replace reagent well contents	2-004 incubate for 00:30:00 2-005 pause for user action 'Stop Reaction: Replace	
-35 <sup>°</sup>			30 -	wave index 3-2	3-001 separate for 03:00:00 at 55.0 V with wave in	
-30			25-	e index 3-1 ave index 3-1	3-002 elute for 01:30:00 at 50.0 V with wave index 3-003 reverse for 00:00:05 at 25.0 V with wave ind	
-25 Date and Time	<u>د ما ما ما م</u>		15-			
-20 05 Mar 2018 02:40:25			10 -			
-15 Time to Next User Event			5-			
5:00 05:30 06:02 <b>00:00:00</b>	04:00 04:30 05:00 05	2:00 02:30 03:00 03:30 Time, hh:mm	0-0-00:30 01:00 01:00	v		
			Check drive protect			
Display Info Shutdown	Data Die	Clear Run Da	Workflow Stop Work	n Workflow	Check Current 📄 Run Work	~
Display Info	Data Dis	Clear Run Da	Check drive protect Workflow Stop Work	n Workflow	Check Current Run Work	

#### HLS <u>Workflows</u> can be viewed, created, and edited in the <u>Workflow Editor</u>.

Once an existing workflow is loaded into the Editor, each component stage used by the workflow is highlighted in yellow.

Main Screen	Workflow Editor	Log Review	System Options	Stage Editor	Factory Settings	Data Acquisition
			Workflow File			
			WORNOW File			
		12	Core_Workflows\CATCH 100-300kb ext	1h sep3h		
	5 to 1 - 0					
	Extraction Sta		Treatment Stage		Collection Stage	
	Core_Stages\Extraction Method 1hr	🔺 🕴 🕻	ore_Stages\CATCH Method 1(HIT kit)	Core_Sta	ges\CATCH 100-300kb sep3h	▲
	Core_Stages\Extraction Method 3hr	C	ore_Stages\Fragmentase Method 1(HEX kit)	Core_Sta	ges\CATCH 100-300kb sep4h	
	Core_Stages\Rinse			Core_Sta	ges\CATCH DC55V sep45m	
	Core_Stages\temp-test			Core_Sta	ges\CATCH DC55V sep75m	
				Core_Sta	ges High-Pass 300kb	
				Core_Sta	ges HMW DC55V sep 75m elu45m	
				Core_Sta	gesynmin DC55V sep75m	
				Core_Sta	yesynmw method 1 Stages/CATCH 100-400kb con2k	
				Non-Core	Stages/CATCH 100-400kb sep3n	
				Non-Core	Stages/CATCH 145kb	-01
				Non-Core	Stages\CATCH 200kb	
				Non-Core	Stages\CATCH 400kb	
				V Non-Core	Stages High-Pass 250kb	T
			Step Table			
	Step		Description			
	1-001 pause for user action 'Re	nove contents of reagent well and sa	ample well. Load 230ul of HLS Lysis reagent (	A) in to reagent well, then load 70u	ul of prepared sample in to the sample well. Se	a
	1-002 separate for 01:00:00 at	55.0 V with wave index 1-1		1700 V 1 0 1		
	2-001 pause for user action 'Rei	nove tape seal. Start Cas9 Reaction:	: Replace sample well contents with 80ul of 0	ATCH reaction mix. Replace reager	nt well contents with 230ul of enzyme buffer (	<u>C)</u>
	2-002 separate for 00:01:00 at	55.0 v with wave index 2-1	(			
	2-003 pause for user action Re	blace sample well contents with 8001	of enzyme buffer (C)			
	2-004 Incubate for 00:30:00	n Reactions Replace reagent well con	stants with 220 of HIS Lysis Reasont (A) An	ly tapa coal. Add rupping buffer to	the consette to refil '	-
	3-001 separate for 03:00:00 at	55.0 V with wave index 3-2	iterits with 2000 HLS Lysis Reagent (A). App	iy tape seal. Add furning burrer to	the cassette to renii.	- 1
	3-002 elute for 01:30:00 at 50	V with wave index 3-1				
	3-003 reverse for 00:00:05 at 2	5.0 V with wave index 3-1				
			Existing	Workflows ca	n be loaded into	
			2/10 11 18			
			🚽 the Edit	or using this h	utton	7
			the Luit			
			Changes Pending			
	New Mar	skillow 🗋 📭 🗛		Changes Cours	Workflow	
	New Wo	Load Workt		Save Save	Save Workhow As	

Step numbering format is X-YYY, where X indicates stage number, and YYY indicates the step number in the X stage definition.

### Notes on HLS-CATCH Extraction (Stage 1)

Extraction time considerations: Sage has found that a variable amounts of non-specifically cleaved DNA (50kb to 200kb) is liberated from non-viable cells during the HLS extraction step. The 1 hour extraction time doesn't remove all of these non-specific fragments, and so they will contaminate the specific targets when using the 1 hr extraction time.

Current "Core" CATCH Workflows

CATCH 100-300kb extr1h sep3h.shflow CATCH 100-300kb extr1h sep4h.shflow CATCH 100-300kb extr3h sep3h.shflow CATCH 100-300kb extr3h sep4h.shflow CATCH DC55V extr1h sep45m.shflow CATCH DC55V extr1h sep75m.shflow CATCH DC55V extr3h sep45m.shflow

This non-specific contamination is <u>actually beneficial</u> when library construction and sequencing is carried out with the <u>10x Genomics Chromium</u> system. *So the <u>1hr</u>* <u>extraction workflows</u> are recommended for <u>10x Genomics</u> customers.

For other sequencing platforms (<u>PacBio and Oxford Nanopore</u>), which employ less efficient library prep procedures, purer CATCH target products are needed, and the <u>**3hr**</u> extraction workflows are recommended.

### Notes on HLS-CATCH Stage 3 Collection Stages

Sage R&D is actively developing new electrophoresis conditions for CATCH applications. Currently these efforts are focused on increasing the size range and resolution of the Stage 3 Collection electrophoresis step. Workflows that have been more thoroughly tested are released as "Core" workflows, while less tested workflows are released as "non-core".

### **Current "Core" CATCH Workflows**

CATCH 100-300kb extr1h sep3h.shflow CATCH 100-300kb extr1h sep4h.shflow CATCH 100-300kb extr3h sep3h.shflow CATCH 100-300kb extr3h sep4h.shflow CATCH DC55V extr1h sep45m.shflow CATCH DC55V extr1h sep75m.shflow CATCH DC55V extr3h sep45m.shflow

Workflow names for HLS-CATCH follow the convention:

CATCH <collection electrophoresis waveform name> extrXX(h or m) sepYY(h or m).

where XX denotes extraction time, and YY indicates collection stage time, and "h", "m" indicate time units of hours or minutes, respectively.

### Notes on HLS-CATCH strategies for size selection and Stage 3 Collection Stages (cont.)

### Target size considerations:

The "100-300kb" waveform has been successfully tested for 200kb CATCH targets with 3 hour separations, and for 400kb targets with 4 hour separations (see slide 45). It has also been tested for 100kb CATCH targets with the 3 hour separation time.

The "DC55V" waveform has been used successfully for CATCH targets up to 16 kb in size with both 45 and 75 minute separation times. With the 75 minute separation time, the CATCH target range should extend up to 30kb. Current "Core" CATCH Workflows

CATCH 100-300kb extr1h sep3h.shflow CATCH 100-300kb extr1h sep4h.shflow CATCH 100-300kb extr3h sep3h.shflow CATCH 100-300kb extr3h sep4h.shflow CATCH DC55V extr1h sep45m.shflow CATCH DC55V extr1h sep75m.shflow CATCH DC55V extr3h sep45m.shflow CATCH DC55V extr3h sep45m.shflow

### Cas9 enzyme assembly for HLS-CATCH

### **Overview of Cas9 enzyme assembly process**

The following protocol assumes use of IDT ALT-R<sup>™</sup> two-part synthetic guide RNAs, and S. pyogenes wild-type Cas9 enzyme from New England Biolabs. We have had consistently good results with these materials.

This protocol assembles the active Cas9 reaction mix in three steps.

- 1) The two-part guide RNAs are annealed by heating to 95C and cooling to room temperature.
- 2) The annealed guide RNAs are mixed with the Cas9 enzyme and incubated briefly at 37C.
- 3) The final assembled enzyme is diluted to the correct volume (80 ul) for loading into the HLS sample well.

### Step 1. Annealing the two-part IDT ALT-R<sup>™</sup> guide RNAs

Dissolve each of the crRNAs and tracrRNAs to be used at **100uM** concentration in IDT Duplexing Buffer. The correct volume for resuspension in microliters will be 10 times the number of nanomoles of RNA in the tube supplied by IDT.

#### To a 200 ul PCR tube add:

1) 15.4 ul IDT duplexing buffer.

**2)** 4 ul of a pooled mixture of all crRNAs used in the experiment. To make the pool, combine equal volumes of each stock crRNA solution. All crRNAs stock solutions should be at 100 uM, in IDT Duplexing Buffer.

(For instance, if two crRNAs are to be used, add 2 ul of each crRNA solution. If four crRNAs are to be used, add 1 ul of each crRNA solution. For more crRNAs, mix equal volumes of each crRNA (using some convenient volume), and then add 4 ul of the resulting crRNA mixture to the PCR tube. The goal here is to saturate the tracrRNA with a 1.5-fold molar excess of total crRNA.)

Mix the duplex buffer and crRNAs thoroughly by vortexing or pipetting, and spin down briefly.

```
3) Add 2.6 ul of tracrRNA (100 uM).
```

Mix thoroughly and spin down briefly. (Vol. =22 ul. Conc. after this step = 11.8 uM tracrRNA, 18 uM total

pooled crRNA.)

**4)** Heat the 20 ul mixture for 5 minutes at 95C in a thermal cycler with a heated lid, then remove the tube from the cycler and allow to cool on the lab bench at room temp for 3-5 minutes. Centrifuge for 30-60 seconds to collect any condensation.

Total volume of the annealed RNA will be approximately 22 ul.

(We have found that annealed guide RNAs can be stored for at least 3 weeks at -20C with no loss of activity.) CATCH Guide for SageHLS, March 2018

### Step 2. Assemble annealed guide RNAs and Cas9

#### Add in order:

- 1) 10 ul Sage HLS 4X Enzyme Buffer.
- 2) 22 ul annealed IDT guide RNAs (from Step 1). Mix thoroughly by vortexing or pipetting and spin down briefly.
- **3)** 8 ul NEB wild-type S. pyogenes Cas9 enzyme (20 uM). Mix thoroughly by gentle pipetting of entire mixture (40ul). Conc. after this dilution step: 4 uM Cas9 enzyme, 6.5 uM annealed tracrRNA.
- 4) Incubate mixture at 37C for 10 minutes to assemble enzyme and gRNAs. Proceed to dilution (step 3), or store on ice until ready.

### Step 3. Dilute to loading concentration with HLS Enzyme Buffer.

**Dilute** assembled Cas9 mixture from Step 2 (40ul), with 40 ul of HLS Enzyme Buffer. Mix thoroughly by gentle pipetting of the entire mixture (80 ul). (Final conc: 2 uM Cas9 assembled with 3.25 uM pool of annealed two-part gRNAs)

At this point the Cas9 mixture is ready to load in the HLS sample well. The mixture can be stored on ice, or at 4C, for several hours.

(According to some of our customers, the assembled ready-to-load Cas9 mixtures is stable for at least 48 hours at 4C. We will be testing 4C storage of assembled enzyme and will report when we have data.)

### **HLS Cassette Preparation**

### **HLS Cassette Preparation- Collecting trapped bubbles.**

Hold the sealed cassette with its surface plane vertical to the ground. Keeping the cassette surface vertical, slowly rotate the sealed cassette 360 degrees while tapping the top surface of cassette to remove all trapped air bubbles from the elution channels. Collect all the bubbles into one end of the reservoirs (either end is OK). The collected bubbles will escape after the cassette is opened and topped up with buffer before run.

Trapped air bubbles that interfere with elution





### SageHLS – Cassette Preparation: Remove tape, Top-up buffer, Perform current check.

- 1. Grasp tabbed edge of sealing tape with one hand, hold cassette firmly in nest with other hand.
- 2. With a slow side-to-side movement, slowly peel off sealing tape. Go slow. Avoid contact with buffer in electrode port openings.
- 3. Completely empty and refill all the elution modules in each lane to ensure no bubbles are trapped inside. (Keep pipette tips vertical to avoid scraping membranes on each side of the elution module.) The elution modules hold approximately 80-85 ul of buffer. Refill each module with 80 ul of Running Buffer.
- 4. Top up the volume of the Reagent and Sample wells. These wells should have a slight concave meniscus when properly filled. The maximum volumes of the wells are approximately 270 and 85 ul, respectively.
- 5. Completely fill the electrode buffer chambers with Running Buffer. The electrode channels at the ends and sides of the cassette should be filled level with the top surface of the cassette.
- 6. Close lid, perform current check on lanes to be used for the experiment. (See next page for instructions on performing current check).

### **Current check procedure (brief version)**

- 1. Select workflow file.
- 2. Choose lanes to be used.
- 3. Close lid. Click "Check Current"



### **Current Check Procedure (cont.)**

Pop-up "Current Check" window appears. Click on "Start".

Lid lock will click, and elevator will be heard.

	Workflow Editor	Log Review	System Options
		Workflow File	
		Cons. West-Revealed to DOSEN with the one 45m	
		Core_worknows/CATCH DC55V extr In sep45m	
		Nest Configuration	
			]
	Surren State	: Check	X
Voltage, V Lid S	atus Lock Status System Sta		e Well Temperature
0.0	ready Cassette		-75
			-73 ▼ T-1,2 0.0
	Step Table Separation		-70 ₹ I-3 0.0
Step	Description		-65 📝 I-4 0.0
1-001 pause for user action	Remove contents of reagent well and sample		-60 🗸 T-3,4 0.0
1-002 separate for 01:00:00	at 55.0 V with wave index 1-1		
2-001 pause for user action	Remove tape seal. Start Cas9 Reaction: Repl		
2-002 separate for 00:01:00	at 55.0 V with wave index 2-1	N	-50 륫
2-003 pause for user action	Replace sample well contents with 80ul of enz		-45 P
2-004 incubate for 00:30:00		Start Return	_40 <sup>1</sup>
2-005 pause for user action	Stop Reaction: Replace reagent well contents		č
3-002 elute for 01:30:00 at	at 55.0 V with wave index 3-1	75 -	
3-003 reverse for 00:00:05	at 25.0 V with wave index 3-1	20 -	-30
		15-	-25 Date and Time
		15-	-20 05 Mar 2018 16:02
		10-	
		5-	Time to Next User E
		Time, hh:n	nm    00:00:0
		Simulation mode   Check drive protection	
Check Current	Run Workflow 00 Pause Work	flow Stop Workflow 🛛 🗶 Clea	ar Run Data 🛛 🕐 Display Info 🛛 🔀 Shutdown

### **Current Check Procedure (cont.)**

Test takes a couple of minutes, first testing Separation electrodes, then Elution electrodes. After successful current test all boxes will be filled with green checkmarks.

Hit "Return" in popup to get back to "Main".

1	Workflow Editor		Log Review	System Options
			West Barr File	
			WORKHOW File	
			Core_Workflows\CATCH DC55V extr1h sep45m	
			Nest Configuration	
01				
02				
		Current	Check	
Voltage, V Lid S	tatus Lock Status System	Sta Jy Cassette		e Well Temperature -80 -75 ↓ I-1 0.0 ↓ I-2 0.
	Step Table	Separation		-70 ✓ I-3 0.0
Step	Description			-65 V I-4 0.0
1-001 pause for user action	Remove contents of reagent well and samp	Elution		-60 <b>T</b> -3,4 0.0
1-002 separate for 01:00:00	at 55.0 V with wave index 1-1			-55
2-001 pause for user action	Lat 55.0 V with wave index 2-1	epi		g
2-003 pause for user action	Replace sample well contents with 80ul of e	enz		
2-004 incubate for 00:30:00			Start Return	-45 ğ
2-005 pause for user action	Stop Reaction: Replace reagent well conte	nts		-40
3-001 separate for 00:45:00	at 55.0 V with wave index 3-1			-35
3-002 elute for 01:30:00 at	50.0 V with wave index 3-1		23-	-30
3-003 reverse for 00:00:05	at 25.0 V with wave index 3-1		20 -	Date and Tim
			15-	-25
			10 -	-20 05 Mar 2018 16:0
			5-	-15 Time to Neutrilleer
				-10
			00:00 00:20 00:40 01:00 01:20 01:40 02:0 Time, hh:m	0 02:20 02:40 03:00 03:20 03:47 00:00:
			Simulation mode   Check drive protection	
Check Current	Pup Workflow	Dause Work	Bow Stop Workflow	r Pun Data Display Info
Check Current	Kull WORNOW	Fause Work		

### **HLS-CATCH Workflow and User Actions**

### Main screen: Ready to start Stage 1- Extraction

### Click "Run Workflow" command.

### (Command is only active after lid is closed.)

	Workflow File		
	Core_Workflows\CATCH DC55V extr1h sep45m		
	Nest Configuration		
Lock Status System Status ready able cription contents of reagent well and sample v with wave index 1-1 tape seal. Start Cas9 Reaction: Reple v with wave index 2-1 sample well contents with 80ul of enz	Electrophoresis Co 80 - 75 - 70 - 65 - 60 - 55 - 50 - 45 - 50 -	2urrent and Sample Well Temperature -75 -70 -65 -60 -55 -50 -50 -55 -50 -50 -55 -50 -55 -50	✓       I-1       0.0         ✓       I-2       0.0         ✓       T-1,2       0.0         ✓       I-3       0.0         ✓       I-4       0.0         ✓       T-3,4       0.0
ction: Replace reagent well contents	35-	-40	
/ with wave index 3-1 th wave index 3-1	25-	-35	
with wave index 3-1	20-	-25	Date and Time
	10-	-20	05 Mar 2018 16:0
	5-	-15	Time to Next User
v	0	0 02:00 02:20 02:40 03:00 03:20 03:47	00.00.0
	Tin	me, hh:mm	00.00.0
	Lock Status  Lock Status  ready  able  ription  contents of reagent well and sample y  with wave index 1-1 tape seal. Start Cas9 Reaction: Repla  with wave index 2-1  sample well contents with 80ul of enz  ction: Replace reagent well contents  / with wave index 3-1  with wave index 3-1	Workflow File         Core_Workflows\CATCH DC55V extr 1h sep45m         Nest Configuration         03       Image: Configuration         04       Image: Configuration         05       Image: Configuration </td <td>Workflow File           Core_Workflows/CATCH DCSSV extr 1h sep45m           Nest Configuration           09         09         09         00<!--</td--></td>	Workflow File           Core_Workflows/CATCH DCSSV extr 1h sep45m           Nest Configuration           09         09         09         00 </td

Popup window prompts user to replace sample and reagent well contents with sample and lysis reagent. See following slides for detailed instructions.

ain Screen	Workflow Editor	Log Review	System Options
		Workflow File Core_Workflows\CATCH DC55V extr 1h sep45m Nest Configuration 03 03 04 04 04 04 04 04 04 04 04 04 04 04 04	
Voltage, 1 0.0 Step 1-001 pa 1-002 se 2-001 pa 2-002 se 2-003 pa 2-004 in 2-005 pa 3-001 se 3-002 el 3-003 re	V Lid Status Lock Status System Status Step Table Description ause for user action 'Remove contents of reagent well and sample's eparate for 01:00:00 at 55.0 V with wave index 1-1 ause for user action 'Remove tape seal. Start Cas9 Reaction: Reple eparate for 00:10:00 at 55.0 V with wave index 2-1 ause for user action 'Replace sample well contents with 80ul of enz nuclbate for 00:30:00 ause for user action 'Stop Reaction: Replace reagent well contents parate for 00:45:0.0 V with wave index 3-1 lute for 01:30:00 at 55.0 V with wave index 3-1 everse for 00:00:05 at 25.0 V with wave index 3-1	Electrophoresis Current and Samp Remove contents of reagent well and sample well. Load 230ul of HLS Lysis reagent (A) in to reagent well, then load 70ul of prepared sample in to the sample well. Seal with tape. 	ple Well Temperature         -80         -75         -70         -65         -65         -60         -55         -60         -55         -60         -55         -50         -70         -61         -62         -55         -50         -50         -70         -55         -60         -55         -50         -70         -50         -50         -70         -50         -50         -50         -70         -50         -70         -50         -50         -70         -73         -73         -73         -73         -73         -73         -73         -73         -73         -73         -73         -73         -73         -73         -740         -75
Ched	dk Current Run Workflow 10 Pause Wo	10 -       5 -       0 -	2:20       02:40       03:00       03:20       03:47         Data       O       Display Info       Image: Construction of the second s

### **Initiating Stage 1- Extraction**

<u>User actions after current-check, at start-of-run pop-up prompt.</u>

- 1) Empty all sample and reagent wells. Take caution not to pierce agarose at bottom of wells.
- 2) Load samples in all lanes. Always use 70ul sample loading volume. (Sample wells will not be completely full.)
- Fill Reagent Wells with HLS Lysis Buffer. <u>Fill, but do not overfill</u>! Leave a concave meniscus to <u>prevent contact with sealing tape</u> in next step. Approximate volume needed will be 220-230 ul.
- 4) Seal reagent, sample, and elution ports with supplied tape. Press tape firmly around edges of ports (see <u>next slides</u> for taping details), and close lid.
- 5) Click on "OK".

### Placement of sealing tape after cassette loading



### Seal tape securely around port borders

The tape is pressure-sensitive. After placing tape on cassette, **press tape tightly to the cassette surface at the edges of the reagent, sample, and elution ports** using a hard, smooth, round object like the back end of a lab marker, or the back side of a curved spatula. Take care **not to press on tape directly over open areas of the ports**, which could force liquid out under the tape.



### Main screen during Stage 1 - Extraction (after 18 min) Current should be similar for all lanes, and in the range of 10-15 mA.

Main Screen	Workflow Editor	Log Review	System Options
		Workflow File Core_Workflows\CATCH DC55V extr 1h sep45m Nest Configuration 03 04 04 04 04 04 04 04 04 04 04 04 04 04	
Voltage, V           54.2           Step           1-001           pause           2-001           2-002           separa           2-003           pause           2-005           3-001           separa           3-002	Lid Status Lock Status System Status Step Table	Electrophoresis Current and Sa 80 - 75 - 70 - 65 - 60 - 55 - 50 - ¥ 45 - 10 - 35 - 30 - 25 -	ample Well Temperature -80 -75 -70 -65 -60 -55 -50 -45 -40 -45 -40 -35
3-003 revers	se for 00:00:05 at 25.0 V with wave index 3-1	20 - 15 - 10 - 5 - 00:00 00:20 00:40 01:00 01:20 01:40 02:00 Time, hh:mm Simulation mode   Check drive protection	-30 -25 -20 -15 -10 02:20 02:40 03:00 03:20 03:47 Date and Time 05 Mar 2018 16:30:05 Time to Next User Event 00:42:13
Check Cur	rrrent Run Workflow 00 Pause W	orkflow Stop Workflow Clear Ru	in Data Display Info Shutdown

### **End of Stage I - Extraction**

Prompts appear in popup window.

See next slide for details on completion of stage 1 and initiation of Stage 2.

Screen	Workflow Editor	Log Review	System Options
01		Workflow File HLS_HMW DNA Extraction Nest Configuration 03 V	
Voltage, V           0.0           Step           1.001           2.002           nubate for user a           2.003           pause for user a           3.001           separate for 01:           3.002           separate for 01:30:           3.004           reverse for 00:0	Lid Status Lock Status System Status Step Table Description 00:00 at 55.0 V with wave index 1-1 socion Remove tape seal. Replace sample well conter 30:00 at 55.0 V with wave index 3-1 15:00 at 55.0 V with wave index 3-1 15:00 at 55.0 V with wave index 3-1 10:05 at 25.0 V with wave index 3-1 0:05 at 25.0 V with wave index 3-1	Electrophoresis Current and Samp Remove tape seal. Replace sample well contents with 30ul of reaction mix. Replace reagent well contents with 230ul Enzyme Buffer (2C). When done, close the lid and click OK to continue.	Image: second secon
Check Current	Run Workflow	5 -         0 -         00:30         01:00         01:30         02:00         02:30         03:00           00:00         00:30         01:00         01:30         02:00         02:30         03:00           Simulation mode   Check drive protection           Ke Workflow         Clear Run D	ata Display Info

### **Completion of Stage 1 Extraction**

Open lid. Remove 2-5 ml of foamy, SDS-rich electrophoresis buffer from the <u>lower separation electrode port</u> of each cassette lane, and discard it.

Remove port sealing tapes by pulling the tabs in a diagonal direction <u>as illustrated on the next slide</u>. (Removing the tape in this manner reduces the risk of introducing liquids from the Reagent or Sample well ports into the elution modules.)

<u>Refill the electrode buffer chamber</u> with fresh electrophoresis buffer so that the buffer level is even with the top surface of the cassette.

### **Completion of HLS Stage 1: Removing tape**



Lower electrode port, remove SDS-rich buffer here after Stage 1.

### **HLS-CATCH Stage 2 (treatment) Overview**

After loading the Cas9 reaction mixture and clicking "OK" on the popup reagent addition prompt, the instrument performs a short electrophoresis pulse (1 minute) to "inject" the Cas9 complexes into the sample gel wall where the DNA is immobilized.

Following the 1 minute injection, the user empties the sample well and refills with HLS Enzyme buffer (without Cas9) to ensure that the Mg<sup>++</sup> concentration remains relatively constant.

### **HLS-CATCH Initiation of Stage 2: Cas9 digestion**

Remove and discard contents of **Sample well** and **Reagent well**.

Add 80 ul of Cas9 reaction mixture to the Sample well.

Fill Reagent well with HLS Enzyme Buffer (without enzyme); approximately 230 ul.

Close lid (do **not** retape the sample/elution ports at this step).

Click "OK" on the popup user prompt to initiate the 1 minute electrophoretic injection.

After injection, replace sample well contents with 80 ul of fresh HLS Enzyme buffer (without Cas9 enzyme).

Close lid (do not retape cassette), and click OK on popup prompt to start Cas9 digestion timer.

### Screen at end of Stage 1/Beginning Stage 2

Popup prompt shows request to replace Sample and Reagent well contents as discussed on previous slide. After these replacements, do not retape. Close lid. Click OK. (Lid lock will click.)

		Workflow File	
		Core_worknows (CATCH DC55V extr in sep45m	
		Nest Configuration	
ſ			]
ſ			]
Voltage, V	Lid Status Lock Status System Status	Electrophoresis Current and Sample	Well remperature
0.0	pause	Remove tape seal. Start Cas9 Reaction: Replace sample	-75
		well contents with 80ul of CATCH reaction mix. Replace	-75 ▼ T-1,2 0.0
	Step Table	reagent well contents with 230ul of enzyme buffer (C).	-70 📝 I-3 0.0
Step	Description	When done, close the lid and click OK to continue.	-65 📝 I-4 0.0
1-001 pause	for user action 'Remove contents of reagent well and sample		-60 V T-3.4 0.0
1-002 separa	ate for 01:00:00 at 55.0 V with wave index 1-1		
2-001 pause	for user action 'Remove tape seal. Start Cas9 Reaction: Repla	OK [Enter]	
2-002 separa	ate for 00:01:00 at 55.0 V with wave index 2-1		-50 g
2-003 pause	for user action 'Replace sample well contents with 80ul of enzy	C 40 -	-45 🛱
2-004 incuba	ate for 00:30:00		
2-005 pause	for user action 'Stop Reaction: Replace reagent well contents		-40 -
3-001 separa	ate for 00:45:00 at 55.0 V with wave index 3-1	30-	-35
3-002 elute f	for 01:30:00 at 50.0 V with wave index 3-1	25-	-30
3-003 revers	se for 00:00:05 at 25.0 V with wave index 3-1	20 -	Date and Time
		15-	
		10-	-20 05 Mar 2018 17:14
		5-	-15
			Time to Next User E
	v		
		Time, hh:mm	00:00:0

### Screen after reagent addition at start of Stage 2.

## Instrument performs <u>1 minute</u> of electrophoresis to inject Cas9 into the sample wall where the HMW DNA is immobilized.

reen	Workflow Editor	Log Review	System Options	
Workflow File Core_Workflows\CATCH DC55V extr 1h sep45m Nest Configuration 01 02 02 0 04 04 04 04 04 04 04 04 04 04 04 04 0				
Voltage, V 54.1 Step 1-001 pause for user 1-002 separate for 0 2-001 pause for user 2-002 separate for 0 2-003 pause for user 2-004 incubate for 00 2-005 pause for user 3-001 separate for 0 2-003 obto fcr 0.0172	Lid Status Lock Status System Status Step Table Description action 'Remove contents of reagent well and sample 11:00:00 at 55.0 V with wave index 1-1 action 'Remove tape seal. Start Cas9 Reaction: Repla 10:01:00 at 55.0 V with wave index 2-1 action 'Replace sample well contents with 80ul of enz 0:30:00 action 'Stop Reaction: Replace reagent well contents 0:45:00 at 55.0 V with wave index 3-1 0:00 at 60.0 with wave index 3-1 0:00 at 60.0 with wave index 3-1	Electrophoresis Cur 80 - 75 - 70 - 65 - 60 - 55 - 50 - 55 - 50	rrent and Sample Well Temperature -80 -75 -75 -77 -77 -77 -77 -77 -77	
Check Current	Run Workflow     Pause V	20           15           10           5           0           00:00           00:20           00:40           01:00           01:20	-30     -30       -25     -20       -20     -15       02:00     02:20       02:00     02:40       03:00     03:20       03:47         Date and Tim       05 Mar 2018       Time to Next User       OO:00:00:       OO:00:00:         Clear Run Data         Display Info         Shutdow	ne : 18:24 r Even <b>32</b>

### Screen after electrophoretic injection of Cas9

# User is prompted to refill **Sample well** with 80ul of HLS Enzyme buffer (without Cas9). Do not retape cassette. Close lid. Click OK. (Lid lock will click.)

en	Workflow Editor	Log Review	System Options
01		Workflow File Core_Workflows\CATCH DC55V extr 1h sep45m Nest Configuration	
Voltage, V Lid	Status Lock Status System Status Step Table Description n 'Remove contents of reagent well and sample 00 at 55.0 V with wave index 1-1 n 'Remove tape seal. Start Cas9 Reaction: Repla 00 at 55.0 V with wave index 2-1 n 'Replace sample well contents with 80ul of enz 0	Electrophoresis Current and Sample V eplace sample well contents with 30ul of enzyme buffer (C). When done, close the lid and click OK to continue.	Vell Temperature
2-005 pause for user actio 3-001 separate for 00:45: 3-002 elute for 01:30:00 a 3-003 reverse for 00:00:0	00 TStop Reaction: Replace reagent well contents 00 at 55.0 V with wave index 3-1 t 50.0 V with wave index 3-1 5 at 25.0 V with wave index 3-1	5 35 - 30 - 25 - 20 - 15 - 0 - 0 - 0 - 0 - 0 - 0 - 0 - 0	-40

### Screen after refilling <u>Sample well</u> with 80 ul of Enzyme buffer Cas9 digestion takes 30 minutes.

		Workflow File	
		Core_Workflows\CATCH DC55V extr1h sep45m	
		Nest Configuration	
	12]		
Voltage V	Lid Status Lock Status System Status	Flectrophoresis Current and Sample Well Temperature	<b>□</b> I-1 00
		80 - 80	▼ I-2 0.0
		75	T-1,2 0.0
	Step Table	70	📝 I-3 0.0
Step	Description	60	📝 I-4 0.0 🛃
1-001 pause for	user action 'Remove contents of reagent well and sample t	55	V T-3,4 0.0
2-001 pause for	user action 'Remove tape seal. Start Cas9 Reaction: Repla	50	-
2-002 separate f	or 00:01:00 at 55.0 V with wave index 2-1	¥ 45-	mpe
2-003 pause for	user action 'Replace sample well contents with 80ul of enz	tj 4045	at l
2-004 Incubate in 2-005 pause for	user action 'Stop Reaction: Replace reagent well contents	특 35 −40	, re,
3-001 separate f	or 00:45:00 at 55.0 V with wave index 3-1	30	
3-002 elute for 0	1:30:00 at 50.0 V with wave index 3-1	25	
5-005 120218210	1 00.00.03 at 23.0 V Will Wave muck 5-1		Date and Time
			05 Mar 2018 17:20:
		5	True to Neutrillon D
		00:00 00:20 00:40 01:00 01:20 01:40 02:00 02:20 02:40 03:00 03:20 03:47 Time. bh:mm	00:29:5
		Tincy finantin	

### Screen after completion of Cas9 digestion.

Prompt will appear: "Stop reaction...".

Empty Reagent well, and refill it with Lysis Buffer.

Carefully tape reagent, sample, and elution ports as for Stage 1. Close lid.

Click "OK" to start Stage 3 - Collection.

Workflow File           Core_Workflows\CATCH DC55V extr 1h sep45m           Nest Configuration           01             02	
Voltage, V       Lid Status       Lock Status       System Status         0.0       Image: Construction of the case o	urrent and Sample Well Temperature -80 -75 -70 -65 -60 -55 -50 -55 -50 -50 -55 -50 -50
2-003 pause for user action 'Stop Reaction: Replace reagent well contents 3-001 separate for 00:30:00 elute for 01:30:00 at 55.0 V with wave index 3-1 3-002 elute for 01:30:00 at 55.0 V with wave index 3-1 3-003 reverse for 00:00:05 at 25.0 V with wave index 3-1 3-004 elute for 01:30:00 at 50.0 V with wave index 3-1 3-005 elute for 01:30:00 at 50.0 V with wave index 3-1 3-006 elute for 01:30:00 at 25.0 V with wave index 3-1 3-007 elute for 00:00:05 at 25.0 V with wave index 3-1 3-000 elute for 00:00:05 at 25.0 V with wave index 3-1 3-000 elute for 00:00:05 at 25.0 V with wave index 3-1 3-000 elute for 00:00:05 at 25.0 V with wave index 3-1 3-000 elute for 00:00:05 at 25.0 V with wave index 3-1 3-000 elute for 00:00:05 at 25.0 V with wave index 3-1 3-000 elute for 00:00:05 at 25.0 V with wave index 3-1 3-000 elute for 00:00:05 at 25.0 V with wave index 3-1 3-000 elute for 00:00:05 at 25.0 V with wave index 3-1 3-000 elute for 00:00:05 at 25.0 V with wave index 3-1 3-000 elute for 00:00:05 at 25.0 V with wave index 3-1 3-000 elute for 00:00:05 at 25.0 V with wave index 3-1 3-000 elute for 00:00:05 at 25.0 V with wave index 3-1 3-000 elute for 00:00:05 at 25.0 V with wave index 3-1 3-000 elute for 00:00:05 at 25.0 V with wave index 3-1 3-000 elute for 00:00:05 at 25.0 V with wave index 3-1 3-000 elute for 00:00:05 at 25.0 V with wave index 3-1 3-000 elute for 00:00:05 at 25.0 V with wave index 3-1 3-00 elute for 00:00:05 at 25.0 V with wave index 3-1 3-00 elute for 00:00:05 at 25.0 V with wave index 3-1 3-00 elute for 00:00:05 at 25.0 V with wave index 3-1 3-00 elute for 00:00:05 at 25.0 V with wave index 3-1 3-00 elute for 00:00:05 at 25.0 V with wave index 3-1 3-00 elute for 00:00:05 at 25.0 V with wave index 3-1 3-00 elute for 00:00 elute for 0	-45 <u>pr</u> -40 <del>0</del> -35 <del>0</del> -30 -35 <u>0</u> -25 <u>0</u> Date and Time -20 <u>15</u> Time to Next User Eve 0 02:00 02:20 02:40 03:00 03:20 03:47

### Main Screen after initiation of Stage 3

In this example, a very short Stage 3 protocol is shown. Other Stage 3's may be as long as 9.5 hrs.

Screen	Workflow Editor	Log Review	System Options
		Workflow File   Workflows\CATCH DC55V extr 1h sep45m  Nest Configuration  03  04  V	
Voltage, V 54.2 Step 1-001 pause for u 1-002 separate fi 2-001 pause for u 2-002 separate fi 2-003 pause for u 2-004 incubate for 2-005 pause for u 3-001 separate fi 3-002 elute for 0 3-003 reverse for	Lid Status Lock Status System Status Step Table	Electrophoresis Current and Sa	mple Well Temperature -80 -75 -75 -70 -65 -60 -55 -60 -55 -50 -45 -45 -40 -45 -35 -30 -25 Date and Time
Check Current	t Run Workflow	0 - 5 - 0 - 0 - 0 - 0 - 0 - 0 - 0 - 0 -	-20       -20         -15       -15         02:20       02:40       03:00       03:20       03:47         In Data       Image: Comparison of the second

### **HLS-CATCH run completed**

This run was simulated in software, so current traces may not be so smooth in a real run. Also, the separation stage used here was very short, other separations may be significantly longer.

**IMPORTANT:** To program next run, you must "Clear Run Data" from previous run.

an	Workflow Editor	Log Review	System Options
		Workflow File Core_Workflows\CATCH DC55V extr 1h sep45m	
		Nest Configuration	
02			
Voltage, V 0.0 Step 1-001 pause for user a 1-002 separate for 01:1 2-001 pause for user a 2-002 separate for 00: 2-003 pause for user a 2-004 incubate for 00: 2-005 pause for user a 2	Lid Status Lock Status System Status Concerning Step Table Description Step Table Description Storo 'Remove contents of reagent well and sample Control to the status of t	Electrophoresis Current and Sample We	ell Temperature -80 -75 -75 -77 -70 -65 -60 -55 -50 -55 -50 -40 -40 -40 -61 -75 -75 -75 -75 -75 -75 -75 -75
3-002 elute for 01:30:0 3-003 reverse for 00:00	00 at 50.0 V with wave index 3-1 00:05 at 25.0 V with wave index 3-1	25 - 20 - 15 - 10 - 5 -	-35 -30 -25 Date and Time -20 06 Mar 2018 08:52:4

### **Completion of HLS-CATCH Workflow**

If possible, remove the eluted DNA within an hour of the end of the run to avoid contamination of the eluted DNA with SDS. The SDS is tightly localized around (+) separation electrode at end of run, but will slowly diffuse throughout the cassette over a period of several hours.

Remove port sealing tapes by pulling the sealing tape tabs in a diagonal direction as discussed previously. (Removing the tape in this manner reduces the risk of introducing liquids from the Reagent or Sample well ports into the elution modules.)

If targeting DNA >100kb, use a wide-bore pipette tip to remove the contents of the elution modules.

**IMPORTANT:** When working with DNA >100kb, pipette as <u>slowly as possible</u> to avoid shearing the HMW DNA. Use of an electronic pipettor at low speed settings may be helpful.

There should be 70-80 ul of liquid in each module.

### Analysis of HLS-CATCH products

To identify the position of CATCH targets in the elution products, we recommend the following procedures:

- 1) Perform a Qubit HS assay to determine total DNA content. (Use 2-5 ul aliquots of elution product.)
- Perform a qPCR assay on all 6 elution products for CATCH target and nontarget (control) genomic sequences to obtain target copy numbers for each EM.

The Qubit assay will give a semi-quantitative evaluation of the quality of the CATCH procedure. When using the 3hr Stage 1 extraction, there is very little total DNA in elution modules 1-5, usually ~2 ng per 80ul, while there will be more in EM #6, sometimes 20-30 ng per 80ul. When using the 1 hr Stage 1 extraction, there will be at least 10 ng of DNA (range 10ng to 200ng) in all elution modules, with higher concentrations in EM #1-3 (up to 200ng).

Whenever possible we prefer to use the "custom" Taqman qPCR assays available from Thermo Life Technologies, but also use the SYBR green kits for regions outside of genes. When using the 1 hour Stage1 extraction we typically see single-plex CATCH target enrichment factors of 15-50x relative to a single copy reference gene like the human RNaseP RNA gene. When using the 3 hr Stage 1 extraction with an input of 300,000-400,000 diploid mammalian cells, we have gotten enrichment factors as high as 700-fold.

### Examples of CATCH target analyses: qPCR and Qubit HS data 200kb and 400kb targets from mouse Brca1 locus 375,000 WBC input load

